

# SKI CARRIER ASSEMBLY INSTRUCTIONS







## **PACKAGE**CONTENT





### **ASSEMBLY**INSTRUCTIONS

1



Tighten T screws into the canal over (B) crossbar.

2



Install C parts to the t-bolts.

3



Insert the ski carrier into t-screws through the holes in the bottom of (A).



### **ASSEMBLY** INSTRUCTIONS

4



Press the button to open the cover and remove the lock on the slide.

5



Move the slide outwards.

6



Fix D brackets by tightening two screws.



#### **ASSEMBLY**INSTRUCTIONS

7



Tighten the both brackets and then lock it by tilting them downwards.

8



Apply the same for the second ski carrier.

9



Load your skis on the slide and push the slide in its place. Be sure that your skies front sides looks at your cars backside.



#### **ASSEMBLY INSTRUCTIONS**



Push the slide all the way through, then push the lock downwards and fix the ski.

#### 11



Close the covers of both carriers.

#### 12



Lock your ski carrier with the key (E).



# SKI CARRIER ASSEMBLY INSTRUCTIONS





